



ORDER BY PART NUMBER, NOT CODE NUMBER

CODE NO.	PART NO.	NO. REQ.	DESCRIPTION	CODE NO.	PART NO.	NO. REQ.	DESCRIPTION
1	5032A	1	Stopper Assembly (Includes Code 2)	24	N/A	1	Sleeve
2	5029	1	Gasket, Stopper	25	71022	1	Rotating Shredder Assembly
3	70966	1	Baffle	26	9209W	1	Upper Endbell Assembly
4	10025B	1	Flange, Strainer	27	1470	1	Gasket, Tailpipe
5	1160	1	Seal, Sink Flange	28	8219	1	Tailpipe
6	5150E	1	Flange, Backup	29	5490	1	Flange, Tailpipe
7	5141	1	Flange, Mounting	30	1491	1	Screw, Tailpipe
8	5147	3	Screw, Backup	31	8628AA	1	Stator Assembly
9	5166	1	Ring, Retaining	32	70422	1	Shaft Assembly (Includes Code 33)
10	1010A	1	Gasket, Mounting	33	2642	1	Washer
11	5298	1	Flange, Body	34	2467	1	Switch, Centrifugal Actuator
12	71952	1	Cap, Trim Shell	35	4134	1	Shield, Wire
13	72103	1	Trim Shell Assembly	36	70360	1	Switch, Start Reverse
14	71953	1	Wrench Holder	37	2267CM	1	Protector, Overload
15	71965	1	Insulation	38	5861	1	Capacitor
16	71788	3	Screw	39	71425	1	Clip, Capacitor
17	9873	1	Body Container Assembly (Includes Code 18)	40	70424	1	Lower End Frame Assembly (Includes Code 42)
18	2539	1	O Ring	41	2486A	2	Bolt, Thru
19	70647	1	Sleeve & Seal Kit (Includes Codes 20 - 24)	42	2466A	1	Screw, Ground
20	2854	1	Plug	43	71387	1	Cover, Terminal
21	N/A	1	Bolt, Hex Head Flange	44	70734	1	Screw, Terminal Cover
22	N/A	1	Slinger	---	72050	1	Care & Use Booklet (Not Shown)
23	N/A	1	Seal	---	2610SP	1	Instruction Ass'y (Not Shown) (Includes Codes 3, 27-30)